



Gateway 600YG2 Battery Replacement

Removal and installation of battery.


Written By: Aaron Brauner



INTRODUCTION

How to remove and install the battery.

Step 1 — Battery



- Flip the laptop over. Slide the battery release tab to the right.

Step 2



- Lift the battery out.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-13 08:05:53 PM.